




HMD925 SERIES POWER FEED MAGNETIC DRILL

OPERATOR'S MANUAL

COVER DRILL PART NUMBERS 0925102, 0925202, 0925104
& 0925204



FOR USE WITH "12,000-SERIES" HOUGEN[®] CUTTERS

HOUGEN®

Portable Magnetic Drill

Model HMD925 Series

Welcome to Hougen

Congratulations on your purchase of the Hougen® Portable Magnetic Drill Model HMD925. Your model is designed to produce superior holes quickly and efficiently. Through constant innovation and development, Hougen is committed to provide you with hole-producing tools and products to help you be more productive.


Before attempting to operate your new Portable Magnetic Drill, please read all instructions first. These include the Operator's Manual and Warning Label on the unit itself. With proper use, care, and maintenance, your model will provide you with years of effective hole drilling performance. Once again, thank you for selecting our product and welcome to Hougen.

Listed below are the Part Numbers and Description of the Hougen HMD925 Series. Please review the Parts Diagram for the location of the Part No. / Serial No. Label.

- 0925102 (HMD925, 115v, Power Feed, Mag. Base with Coolant)
- 0925104 (HMD925, 115v, Power Feed, Mag. Base with Coolant and Swivel)
- 0925202 (HMD925, 230v, Power Feed, Mag. Base with Coolant)
- 0925204 (HMD925, 230v, Power Feed, Mag. Base with Coolant and Swivel)

Specifications

Cutter Type.....	Hougen "12,000-Series"
Hole Capacity.....	7/16" - 1-1/2" Manual Mode
	7/16" - 1-1/4" Power Feed Mode
Depth of Cut.....	2"
Motor.....	120v 450 RPM, 7.2A or 230v 450 RPM, 3.6A
Net Weight.....	37 Lbs. (HMD925 Swivel 40 lbs.)
Swivel Area.....	1-1/8" W x 1-3/8" L



Commercial / Industrial Limited Warranty

Hougen Manufacturing, Incorporated warrants its Portable Magnetic Drills and its Electro-hydraulic Hole Punchers for a period of 1 year and other products for ninety (90) days from date of purchase against defects due to faulty material or workmanship and will repair or replace (at its option) without charge any items returned. This warranty is void if the item has been damaged by accident or unreasonable use, neglect, improper service, or other causes not arising out of defects in material or workmanship. No other expressed warranty is given or authorized. Hougen Manufacturing, Inc. disclaims any implied warranty of MERCHANTABILITY or FITNESS for any period beyond the expressed warranty and shall not be liable for incidental or consequential damages. Some states do not allow exclusions of incidental or consequential damages or limitation on how long an implied warranty lasts and, if the law of such a state governs your purchase, the above exclusion and limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

To obtain warranty service, return the item(s), transportation prepaid, to your nearest Factory Authorized Warranty Repair Center or to Hougen Manufacturing, Inc., 3001 Hougen Drive, Swartz Creek, Michigan 48473.

Hougen Drills are warranted against manufacturing defects only. Subject to Hougen Manufacturing inspection.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

© 2008 Hougen Manufacturing, Inc.

Photographs and Specifications shown are accurate in detail at time of printing. Manufacturer reserves the right to make improvements and modifications without prior notice.

Hougen, Rotabroach, and Hougen-Edge are proprietary trademarks of Hougen Manufacturing Inc.

UNPACKING YOUR NEW MAGNETIC DRILL


1. Open shipping carton and remove the literature and hardware packages.
2. **Read and Follow All Instructions** before attempting to operate your new Magnetic Drill.
3. Complete and mail the Product Registration Card now. It is important that Hougen Manufacturing, Inc. have a record of product ownership.
4. Open hardware package and check contents.
 - 10565 1/8" Hex wrench for Gib Adjustment
 - 04558 Feed handles (3)
 - 04532 Feed handle knobs (3)
 - 90724 Safety chain
 - 02635 3/16" Hex wrench for cutter installation
 - 13013 5/32" Hex wrench
5. Using the handle of Magnetic Drill, lift unit out of the shipping case.
6. Remove all packing and securing material from the drill unit.
7. Screw the three Knobs (04532) into the three Feed Handles (04558) and then screw Handles into the Hub Assembly (19030). Do not overtighten or may strip the knobs.
8. Your Magnetic Drill was factory adjusted prior to shipping. Check to make sure that all gib adjustment screws, motor mount screws, front support bracket screws, and magnet mounting screws are snug and have not vibrated loose in transit.
9. Your new Magnetic Drill comes complete with arbor mounted. The 3/4" diameter arbor bore fits all 3/4"-shank "12,000-Series" Hougen Cutters.

Reread Safety Warnings listed in the Operator's Manual and on the drill unit to avoid injury. Follow operating procedures.

INDEX

WELCOME TO HOUGEN	2	0925102 & 0925202 PARTS LIST	13
UNPACKING YOUR DRILL	3	0925104 & 0925204 DRILL BREAKDOWN	14
SAFETY INSTRUCTIONS	4 - 5	0925104 & 0925204 PARTS LIST	15
SAFETY SWITCH INDICATOR LIGHT	5	MAGNET BREAKDOWNS	16
CONTROL PANEL	6	ARBOR ASSEMBLY BREAKDOWN	17
OPERATING INSTRUCTIONS	7	120v CONTROL PANEL ASSEMBLY	18
INSTALLING HOUGEN CUTTERS	8	230v CONTROL PANEL ASSEMBLY	19
CUTTING FLUID RESERVOIR	8	120v MOTOR SLIDE ASSEMBLY	20-21
SWIVEL BASE INSTRUCTIONS	9	MOTOR BREAKDOWNS	22-25
ARBOR & GIBS ADJUSTMENT	10	MAINTENANCE & TIPS	26-27
0925102 & 0925202 DRILL BREAKDOWN	12	WARRANTY REPAIR CENTERS	28

SAFETY FIRST



Always wear eye protection while using cutting tools, or in the vicinity of cutting.



CAUTION! The slug is ejected at the end of the cut. Do not aim cutter or arbor so that ejected slug may hit someone around, or below you.



CAUTION! Cutters are sharp. Wear gloves when installing or removing cutter from arbor. Do not grab a rotating cutter.



CAUTION! To prevent electric shock, do not use power tools near wet areas, or where power tool may become wet.

Important Safety Instructions



WARNING: When using electric tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

1. Read All Instructions

2. Grounding Instructions

This tool should be grounded while in use to protect the operator from electric shock. The tool is equipped with a 3-conductor cord and a 3-prong grounding type plug to fit the proper grounding type receptacle. The green (or green and yellow) conductor in the cord is the grounding wire. Never connect the green (or green and yellow) wire to a live terminal. (Refer to Plug Diagram) Section A

3. Safe Electrical Connection

Your Mag Drill is rated for use on 115VAC (Plug A) or 230V (Plug B) at 50-60Hz. Do not attempt to use drill on power sources rated other than this. Wet electrical connections are shock hazards. To prevent the cutting fluid from traveling along the cord and contacting the plug or power outlet, tie a drip loop in the power cord. Also elevate extension cords or gang box connections.

4. Extension Cords

Use only 3-wire extension cords that have 3-prong grounding type plugs and 3-pole receptacles that accept the tool's plug. Replace or repair damaged cords. Make sure the conductor size is large enough to prevent excessive voltage drop which will cause loss of power and possible motor damage.

5. Do Not Force Tool

It will do the job better and faster at the rate for which it was intended.

6. Keep Work Area Clean

Cluttered areas and benches invite injuries. Keep dirt and chips from under the Cutter area.

7. Consider Work Area Environment

Do not expose tool to rain.
Do not use tool in damp or wet locations.
Keep work area well lit.
Do not use tool in presence of flammable liquids or gases. Disconnect from power source when changing cutters or maintaining drill.

8. Guard Against Electric Shock

Prevent body contact with grounded surfaces. For example: pipes, radiators, ranges, refrigerator enclosures.

9. Keep Children Away

Do not let visitors contact tool. All visitors should be kept away from work area while in use.

10. Store Idle Tools

When not in use, tools should be stored in a dry, and high or locked-up place — out of reach of children.


11. Use Right Tool

Do not force small tool or attachment to do the job of a heavy duty tool.
Do not use tool for purpose not intended — for example — do not use a circular saw for cutting tree limbs or logs.

Extension Cord Table

LENGTH OF CORD, FEET	RECOMMENDED WIRE GAUGE	RECOMMENDED WIRE GAUGE
	115V MOTOR 10 - 12 AMPS	230 V MOTOR 5 - 6 AMPS
UP TO 25	16	18
26 - 50	14	18
51 - 100	10	16
101 - 200	8	14
201 - 300	6	12
301 - 500	4	10

Plugs and Receptacles



12. Non-Conforming Cutting Tools

Your Mag Drill is designed to use Hogen Cutters. The use of drilling tools having different shank styles is not recommended as they may not tighten securely in the drill arbor with risk of accident or injury.

13. Secure Work

Use clamps or a vise to hold work. It is safer than using your hand and it frees both hands to operate tool.

14. Always Wear Safety Glasses or Goggles

15. Dress Properly

Do not wear loose clothing or jewelry. They might entangle with spinning chips or get caught in moving parts. Rubber gloves and nonskid footwear are recommended when working outdoors. Wear sturdy leather gloves when working indoors. Wear protective hair covering to contain long hair.

16. Do Not Abuse Cord

Never carry drill unit by its cord or yank it to disconnect from receptacle. Keep cord away from heat, oil, and sharp edges.

17. Do Not Overreach

Keep proper footing and balance at all time.

Important Safety Instructions - Continued

18. Maintain Tools With Care

Keep tools sharp and clean for better and safer performance. Do not use dull or broken Hougén Cutters. Follow instructions for lubricating and changing accessories. Inspect tool cords periodically and, if damaged, have repaired by authorized service facility. Inspect extension cords periodically and, if damaged, have repaired by authorized service facility. Keep handles dry, clean, and free from oil and grease.

19. Disconnect Tools

Disconnect when not in use, before servicing, and when changing cutters or accessories.

20. Remove Adjusting Keys and Wrenches

Form a habit of checking to see that keys and wrenches are removed from tool before turning it on.

21. Check Damaged Parts

Before further use of the drill, a part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A part that is damaged should be properly repaired or replaced by an authorized service center unless otherwise indicated elsewhere in this operator manual. Do not operate tool if switch does not turn it on and off.

22. Stay Alert

Watch what you are doing and use common sense. Do not operate tool when you are tired. Have defective switches replaced by authorized service center.

23. Outdoor Use Extension Cords

When tool is used outdoors, use only extension cords intended for use outdoors and so marked.

24. Additional Safety Precautions

Arbor and cutter should never be used as a hand-hold. Keep hands and clothing away from all moving parts. Do not use Hougén Cutters where ejected slug might cause injury (slug ejected at end of cut). Also, adhere to all operating instructions. Do not drill through any surface that may contain live electrical wiring. Drilling into a live wire could cause exposed metal parts of the drill to be made live. Remove chips wrapped around Cutter and arbor after each hole. With motor off and power disconnected, grasp chips with leather gloved hand or pliers and pull while rotating counterclockwise. Should the cutter become jammed in the work, stop the unit immediately to prevent personal injury. Disconnect the drill from the power supply and loosen jammed cutter by turning the arbor counterclockwise. Never attempt to free the jammed cutter by starting the motor. Service at authorized repair center only.

25. Operating Near Welding Equipment

DO NOT operate this unit on the same work surface that welding is being performed on. Severe damage to the unit, particularly the power cord, could occur. This could also result in personal injury to the operator.

26. Circuit Breaker (If Applicable)


Changing of the circuit breaker to a higher amp rated breaker, or bypassing the circuit breaker is not recommended and will void product warranty.

27. Circuit Breaker Operation (If Applicable)

The circuit breaker is a thermal breaker. When it reaches the higher temperature rating it will trip and cause the unit to shut down. This is a protective device and can be reset after 5 to 10. To reset the breaker, press the breaker button back in. If it does not reset, let the unit cool a little longer until you can push the button in and it stays in position.

28. Safe Electrical Connection

Wet electrical connections are shock hazards. To prevent the cutting fluid from traveling along the cord and contacting the plug or power outlet, tie a drip loop as shown. Also elevate extension cords or gang box connections.



29. Save these Instructions.

SAFETY SWITCH INDICATOR LIGHT

The Safety Switch Indicator Light is a Standard Safety Feature on HMD925 magnetic drills. Its purpose is to inform the user that an unsafe condition exists.

If light is Green:

In normal operation the safety switch light will be green. Motor "On" and "Off" Switches function normally.

If light is Red:

A condition with the safety switch exists that needs to be corrected.

Possible causes:

- Safety Switch is defective. Have drill serviced.
- Uneven work surface or material. Check work surface for flatness.
- Dirt or chips under magnet. Clean work surface.


Make sure material is at least 3/8" thick. Material thinner than 3/8" will cause a "weak" magnet condition.

HOUGEN MANUFACTURING RECOMMENDS THAT CONDITIONS ARE CORRECTED SO LIGHT TURNS GREEN. THIS ALLOWS FOR THE UNIT TO BE OPERATED IN A SAFE MANNER.

For any questions please contact Hougén Manufacturing's Technical Service at (810) 635-7111.

OPERATION OF CONTROLS BEFORE INSTALLING HOUGEN CUTTER

IMPORTANT: Before turning on the machine, it is important that the operator understands the interrelated functions of the **SAFETY SWITCH, MAGNET SWITCH, AND MOTOR SWITCHES.**
READ SAFETY SWITCH INDICATOR LIGHT INSTRUCTIONS PREVIOUS PAGE.



SAFETY SWITCH — Located in base of drill. Enables motor operation only when magnet is properly seated on a clean and flat work surface. Turns motor off if switch detects lift of unit.

MAGNET ON/OFF SWITCH — Energizes and De-Energizes the magnetic base and activates the safety switch. Motor can now be started by pushing the motor START switch.

MOTOR START/STOP SWITCHES — Starts and Stops the motor (See instructions previous page).

POWER/MANUAL FEED SWITCH — Enables or disables Power Feed Mode.

1. Place Magnetic Drill on clean, flat steel plate that is at least 3/8" thick.
2. Plug unit into proper AC power source. **DO NOT use with DC Power.**
3. Locate the Magnet **ON** and **OFF** switches and the motor **STOP** and **START** switches.
4. **NOTE: A loss of power will de-energize the magnetic base and deactivate the motor.**

When power is restored, the magnet will reenergize, however, the motor START switch must be depressed before the motor will start.


OPERATING INSTRUCTIONS

Always remember that the magnet's holding power is directly related to the workpiece thickness and surface condition. Since magnetic attraction diminishes with thinner material or rough surfaces, mechanical clamping of drill unit to the workpiece should be used when cutting thin material (3/8" or less) or material with uneven surfaces.


Power Feed Mode

1. Make sure workpiece and bottom of magnet are free of chips, oil, etc.
2. Position drill by sliding it and gently feeding Arbor so that pilot point is touching center of hole to be drilled.
3. Secure unit to workpiece with safety chain.
4. Turn magnet ON by pressing the magnet ON switch.
5. On Control Panel Flip Power/Manual Feed Switch to **Power Feed**.
6. Turn On Cutting Fluid and check for proper flow by slightly depressing pilot on work surface.
7. Make certain that cutter is clear of workpiece by 1/16" - 1/8" and turn motor ON by pressing the motor START switch.
8. In center of feed handles **Flip Power Feed Handle** out to engage Power Feed Motor. The unit will feed itself into and through the workpiece.
9. At conclusion of cut, motor will automatically turn OFF.
CAUTION: Slug can eject with force and distance.
Disengage Power Feed Handle then turn Feed Handles to raise Arbor and make sure slug has fallen free.
10. Turn magnet OFF by pressing the magnet OFF switch.
11. **Disconnect from power source.**
12. If necessary, remove chips from cutter and magnet, preferably wearing leather work gloves and/or with pliers.
13. Disconnect safety chain and you are ready to move unit to new drilling position.

Step 5




Step 8




Manual Feed Mode

1. Make sure workpiece and bottom of magnet are free of chips, oil, etc.
2. Position drill by sliding it and gently feeding Arbor so that pilot point is touching center of hole to be drilled.
3. Secure unit to workpiece with safety chain.
4. On Control Panel Flip Power/Manual Feed Switch to **Manual**.
5. Turn magnet ON by pressing the magnet ON switch.
6. Turn Feed Handle, raising the cutter until the pilot is above the work surface.
7. Turn on coolant bottle.
8. Make certain that cutter is clear of workpiece and turn motor ON by pressing the motor START switch.
9. Feed Cutter slowly into workpiece. Only after cutting path is established to a depth of about 1/16" can full force be applied to feed handles.
10. Ease up on feed pressure as cutter starts breaking through.
11. At conclusion of cut, turn motor OFF by pressing motor STOP switch.
CAUTION: Slug can eject with force and distance.
Turn Feed Handles to raise Arbor checking to make sure the slug has fallen free.
12. Turn magnet OFF by pressing the magnet OFF switch.
13. **Disconnect from power source.**
14. If necessary, remove chips from cutter and magnet, preferably wearing leather work gloves and/or with pliers. Disconnect safety chain and you are ready to move unit to new drilling position.




INSTALLING HOUGEN CUTTER IN ARBOR

1. Disconnect from power source.
2. Lay drill on its side with feed handles up or be sure Arbor clears table if unit is in normal operating position.
3. Turn Feed Handles until cutter mounting set screws are exposed and completely remove the set screw.
4. Insert proper pilot in shank end of Hougen Cutter.
5. Insert Hougen Cutter until flat on cutter shank is aligned with set screw holes and is exactly perpendicular to axis of set screw holes.
6. Insert set screws and tighten.



INSTALLATION OF COOLANT BOTTLE

The Coolant Bottle is Attached as follows:



SWIVEL BASE OPERATION


ATTENTION

The threads on the Clamp Handle Assembly are a Left Handed thread meaning,
Turning Clockwise would loosen the assembly
Turning Counter Clockwise would tighten the assembly.


Also, the Clamp Handle Assembly is spring loaded so you will need to lift & turn the entire Clamp Handle Assembly when repositioning as if to be a ratchet device.

To Loosen the Swivel Plate Assembly

1. Lift the Clamp Handle Assembly, rotated counter-clockwise and release .
This will reposition the lever for more movement.



2. With the Clamp Handle Assembly now down, pull the Clamp Handle Assembly clockwise.



With this being a left handed thread this will loosen this assembly.

3. If more travel is needed lift the Clamp Handle Assembly, rotate counter clockwise and release.


4. Pull the Clamp Handle Assembly clockwise again.

This amount of movement should be adequate to reposition the Drill Assembly.


More movement than this may cause the Magnet Assembly to disengage from the drill base.

To Tighten the Swivel Plate Assembly.

1. Lift the Clamp Handle Assembly, rotated clockwise and release .
This will reposition the lever for more movement.



2. With the Clamp Handle Assembly now down, push the Clamp Handle Assembly counter clockwise.



With this being a left handed thread this will tighten this assembly.

3. If more travel is needed lift the Clamp Handle Assembly, rotate clockwise and release.


4. Push the Clamp Handle Assembly counter clockwise again.

Continue this process until the Swivel Assembly is tight.



WARNING :
CLAMP HANDLE MUST BE TIGHT PRIOR TO CUTTING HOLES -
EQUIPMENT DAMAGE OR PERSONAL INJURY COULD OCCUR

OPERATION OF CUTTING FLUID RESERVOIR



1. With Drill in operating position, turn the feed handles so that cutter and pilot are above the work surface.
2. Fill reservoir by removing cap on bottle.
3. **Turn on coolant bottle.**
4. Test metering capabilities of Arbor/Cutter/Pilot assembly (magnet ON-motor OFF) by feeding the Arbor gently toward work surface until pilot is pushed up into Cutter, thus allowing fluid to filter down onto work surface through a groove in the pilot.
5. Fluid output can be adjusted by position of On/Off Valve.

ADJUSTMENT OF GIBS

1. Loosen all Gib Screws.
 2. Feed the drill in and out a few times and then, with top of motor slide flush with top of housing, tighten the Gib Screws until you feel them touch the Steel Gib.
 3. Feed the drill in and out again.
 4. Adjust Gib Screws so that there is uniform pressure from top to bottom. (Top of motor slide flush with top of housing.)
 5. Turn each Gib Screw in about 1/8 to 1/4 turn, depending upon your preference.
 6. Gibs should be tight enough so that slide moves up and down smoothly with no wobble or shaking. (Looseness will cause cutter breakage.)
- NOTE: Gibs should be lubricated regularly.**

ARBOR & FRONT SUPPORT BRACKET REMOVAL AND INSTALLATION

Removal

1. Remove coolant bottle. (see previous page)
2. Loosen arbor support bracket bolts.
3. Loosen set screws holding arbor on motor output shaft.
4. Remove arbor.

Installation

1. Hand tighten front support bracket bolts. Do not tighten all the way.
2. Slide arbor to full up position and hold arbor in position over hex drive motor output shaft.
3. Tighten two set screw to hold arbor onto motor output shaft.
4. Turn feed handle until motor and arbor are at the bottom of their travel. Tighten arbor support bracket bolts to 400 in/lbs
5. Install coolant bottle. (see installation previous page)
6. Run motor for 10 seconds. (If visual movement of arbor is noticed, restart at step 1)
7. Re-check for tightness of arbor set screws.

ARBOR ADJUSTMENT

Adjust Gibs before adjusting front support bracket.


1. Loosen Arbor Support Bracket Bolts.
2. Be sure top of arbor is flush with the shoulder on motor output shaft. Also make certain arbor is securely fastened.
3. Turn feed handle until motor and spindle are at the bottom of their travel.
4. Tighten Arbor Support Bolts.
5. Feed slide up and down a few times, checking for free and uniform movement.

NOTE: Check Arbor support bolts regularly to make certain they are tight. Tighten as required.

NOTES

0925102 HMD925 120v Power Feed with Coolant

0925202 HMD925 230v Power Feed with Coolant




0925102 & 0925202 Parts List

Item	Part #	Description	Qty	Item	Part #	Description	Qty
1	*05378	Magnet & Switch Assembly 120v	1	20	19016	20 Tooth Gear	2
	*05392	Magnet & Switch Assembly 230v	1	21	19017	.4375 Diam. Shaft	2
2	*07155	Arbor & Front Support Bracket Assembly	1	22	19020	Gear Spacer	4
3	07127	Housing Assembly 120v (includes 3a-3d)	1	23	19018	Travel Switch Block	1
	19036	Housing Assembly 230v (includes 3a-3d)	1	24	10836	Retain. Ring	1
3a	05108	Bronze Bearing	2	25	01165	Retain. Ring 1/2 Shaft	3
3b	40237	Set Screw 1/4-28 X 1/2	4	26	05114	Spring	1
3c	19024	Engagement Label	1	27	05115	Flat Washer	1
3d	07026	Safety Label Instructions 120v	1	28	19040	Handle Lever	1
	19022	Safety Label Instructions 230v	1	29	19021	Motor Label	1
4	*19037	Control Panel Assembly 120v	1	30	40077	Screw SHC 1/4-20 X 1	1
	*19043	Control Panel Assembly 230v	1	31	02460	Hex Bolt 3/8-24 X 2-3/4	2
5	*05485	Motor Slide Assembly 120v	1	32	90077	Screw BHC #10-32 X 1/2	3
	*07182	Motor Slide Assembly 230v	1	33	10553	Screw SHC 1/4-20 X 7/8	2
6	07163	Coolant Inducer Bracket	1	34	10648	Screw SHC #10-32 X 1/2	1
7	02429	Right Hand Brass Gib	1	35	41044	Screw BHC #10-32 X 3/8	4
8	02430	Left Hand Brass Gib	1	36	05203	Screw SHCS #8-32 X 3/4	2
9	02431	Steel Gib	1	37	05357	Set Screw 1/4-28 X 7/8	1
10	19026	Feed Motor Assembly (includes 10a-10b)	1	38	90028	Lock Washer 1/4	3
10a	19027	Motor Gear	1	39	40392	Flat Washer 3/8	2
10b	02217	Set Screw #8-32 X .18	1	40	40391	Lock Washer	2
11	19028	Gear #1 Assembly	1	41	40038	Screw SHC #10-32 X 5/8	1
11a	24100	Ball Bearing	3	42	10560	Lock Washer	1
12	19029	Gear Shaft Clutch Assembly (includes 12a - 12b)	1	43	41048	Screw SHC #10-32 X 1-1/2	4
12a	05107	Ball Bearing 35mm X 47mm X 7mm	1	44	51044	Screw SHC #10-32 X 1-1/4	2
12b	24100	Ball Bearing	1	45	02902	Roll Pin 1/8 X 5/8	1
13	19030	Feed Hub w/Spline Assembly	1	46	40277	Dowel Pin 3/16 X 5/8	1
14	19004	Gear Box Assembly	1	47	05187	Screw SHC #2-56 X 1/2	2
15	19005	Clutch Drive	1	48	19042	Limit Switch	1
16	19008	Gear w/Spline	1	49	19022	Safety Instruction Label	1
17	90571	Power Cord Assembly 120v	1	50	05207	Jumper Wire	1
	05302	Power Cord Assembly 230v	1	51	*05060	Coolant Bottle Assembly	1
18	19010	Hub Plate	1	52	04558	Feed Handle .50 X 4.50	3
19	19013	Spline Shaft	1	53	04532	Oval Knob	3

* SEE FOLLOWING PAGES FOR ASSEMBLY BREAKDOWNS


0925104 HMD925 120v Power Feed with Coolant & Swivel Base
0925204 HMD925 230v Power Feed with Coolant & Swivel Base




0925104 & 0925204 Parts List

Item	Part #	Description	Qty	Item	Part #	Description	Qty
1	*05648	Magnet & Switch Assembly 120v	1	22	19020	Gear Spacer	4
	*05894	Magnet & Switch Assembly 230v	1	23	07070	Travel Switch Block	1
2	*07156	Arbor & Front Support Bracket Assembly	1	24	10836	Retain. Ring	1
3	19036	Housing Assembly (includes 3a-3d)	1	25	01165	Retain. Ring 1/2 Shaft	3
3a	05108	Bronze Bearing	2	26	05114	Spring	1
3b	40237	Set Screw 1/4-28 X 1/2	4	27	05115	Flat Washer	1
3c	19024	Engagement Label	1	28	19040	Handle Lever	1
3d	19022	Safety Label Instructions	1	29	19021	Motor Label	1
4	*19037	Control Panel Assembly 120v	1	30	40077	Screw SHC 1/4-20 X 1	1
	*19043	Control Panel Assembly 230v	1	31	05736	Hex Bolt 3/8-24 X 2	2
5	*05965	Motor Slide Assembly 120v	1	32	90077	Screw BHC #10-32 X 1/2	3
	*07183	Motor Slide Assembly 230v	1	33	10553	Screw SHC 1/4-20 X 7/8	2
6	07163	Coolant Inducer Bracket	1	34	10648	Screw SHC #10-32 X 1/2	1
7	02429	Right Hand Brass Gib	1	35	41044	Screw BHC #10-32 X 3/8	4
8	02430	Left Hand Brass Gib	1	36	05203	Screw SHCS #8-32 X 3/4	2
9	02431	Steel Gib	1	37	05357	Set Screw 1/4-28 X 7/8	1
10	19026	Feed Motor Assembly (includes 10a-10b)	1	38	90028	Lock Washer 1/4	3
10a	19027	Motor Gear	1	39	40392	Flat Washer 3/8	2
10b	02217	Set Screw #8-32 X .18	1	40	40391	Lock Washer	2
11	19028	Gear #1 Assembly	1	41	40038	Screw SHC #10-32 X 5/8	1
11a	24100	Ball Bearing	3	42	10560	Lock Washer	1
12	19029	Gear Shaft Clutch Assembly (includes 12a - 12b)	1	43	41048	Screw SHC #10-32 X 1-1/2	4
12a	05107	Ball Bearing 35mm X 47mm X 7mm	1	44	51044	Screw SHC #10-32 X 1-1/4	2
12b	24100	Ball Bearing	1	45	02902	Roll Pin 1/8 X 5/8	1
13	19030	Feed Hub w/Spline Assembly	1	46	40277	Dowel Pin 3/16 X 5/8	1
14	19004	Gear Box Assembly	1	47	05187	Screw SHC #2-56 X 1/2	2
15	19005	Clutch Drive	1	48	19042	Limit Switch	1
16	19008	Gear w/Spline	1	49	19022	Safety Instruction Label	1
17	90571	Power Cord Assembly 120v	1	50	05207	Jumper Wire	1
	05302	Power Cord Assembly 230v	1	51	*05060	Coolant Bottle Assembly	1
18	19010	Hub Plate	1	52	04558	Feed Handle .50 X 4.50	3
19	19013	Spline Shaft	1	53	04532	Oval Knob	3
20	19016	20 Tooth Gear	2	55	05207	Jumper Wire	1
21	19017	.4375 Diam. Shaft	2	56	07015	Lock / un-lock label	1


* SEE FOLLOWING PAGES FOR ASSEMBLY BREAKDOWNS





05378 Magnet Assembly 120v 05391 Magnet Assembly 230v			
Item	Part #	Description	Qty
1	05377	Magnet Assembly 120v	1
	05391	Magnet Assembly 230v	1
2	04885	Safety Switch Assembly	1
3	04910	Plunger Assembly	1
4	04909	Safety Switch Bracket	1
5	10983	Micro Switch Shield	1
6	10971	Screw SHC 1/4-20 X 1/2	2
7	10972	Screw BHC #6-32 X 7/8	2
8	17271	Tapered Spring	1




05648 Swivel Magnet Assembly 120v 05894 Swivel Magnet Assembly 230v			
Item	Part #	Description	Qty
1	05649	Magnet/Safety Switch Assembly 120v includes a-c	1
	05895	Magnet/Safety Switch Assembly 230v includes a-c	1
a	05650	Magnet Assembly 120v	1
	05896	Magnet Assembly 230v	1
b	05652	Ball Switch Assembly	1
c	04910	Plunger	1
2	05743	Screw FHC 1/4-20 X 3/4	6
3	05657	Slide Housing	1
4	05656	Swivel Housing	1
5	01169	Dowel Pin 1/8 X 3/8	1
6	05658	Pivot Rod	1
7	05659	Clamp Handle Assembly	1
8	10771	Grommet	1





07155 Coolant Arbor Assembly 07156 Coolant / Swivel Arbor Assembly			
Item	Part #	Description	Qty
1	07157	Arbor & Collar Assembly	1
a	07159	Arbor Body	1
b	07162	Ejection Collar	1
c	07161	Spring Seat	1
d	10517	Retain. Ring	2
e	05049	Spring	1
f	40312	Roll Pin	1
g	10506	Set Screws 3/8-24 X .305	2
h	07083	Set Screw m6 X 1 X 5mm	2
i	05628	Set Screw 1/4-28 X 3/8	2
2	07158	Coolant Inducer Assembly	1
j	07160	Inducer Ring	1
k	40300	O-Ring	2
l	40301	Washer	2
m	40302	Retain Ring	2
n	07080	Hose Fitting	1
3	04375	Front Support Bracket Assembly used with 07155 Assembly	1
	05734	Front Support Bracket Assembly used with 07156 Assembly	1
o	40232	Needle Bearing	1
4	40234	Thrust Washer	2
5	40398	Retain. Ring	2
6	04391	O-Ring	1





19037 120v Control Panel			
Item	Part #	Description	Qty
1	05831	Faceplate	1
2	05852	Power Feed Circuit Board	1
3	05826	Circuit Board	1
4	04614	Rocker Switch	1
5	05871	Motor ON Switch	1
6	04644	Green Switch Cover	1
7	05335	Mini Toggle Switch	1
8	04877	Wire Harness	1
9	04878	L.E.D Spacer	1
10	04878	L.E.D. Bulb	1
11	04879	L.E.D Lens	1
12	05336	Toggle Switch Boot	1
13	05331	Jumper Wire J5-J3	1
14	05332	Jumper Wire J6-J5	1
15	05355	Screw #4-40 X 1/4	5
16	04891	3/8 lg. Standoff	5
17	05832	Nylon Standoff	3
18	05320	Screw #4-40 x 1	3
19	05319	Nylon Nut	3
20	05872	Motor OFF Switch	1
21	04643	Red Switch Cover	1
22	01226	Switch Guard	1






19043 230v Control Panel Assembly			
Item	Part #	Description	Qty
1	05831	Faceplate	1
2	05868	Power Feed Circuit Board	1
3	05827	Circuit Board	1
4	04664	Rocker Switch	1
5	05871	Motor ON Switch	1
6	04644	Green Switch Cover	1
7	05335	Mini Toggle Switch	1
8	04877	Wire Harness	1
9	04878	L.E.D Spacer	1
10	04881	L.E.D. Bulb	1
11	04879	L.E.D Lens	1
12	05336	Toggle Switch Boot	1
13	05331	Jumper Wire J5-J3	1
14	05332	Jumper Wire J6-J5	1
15	05355	Screw #4-40 X 1/4	5
16	04891	3/8 lg. Standoff	5
17	05832	Nylon Standoff	3
18	05320	Screw #4-40 x 1	3
19	05319	Nylon Nut	3
20	05872	Motor OFF Switch	1
21	04643	Red Switch Cover	1
22	01226	Switch Guard	1






05485 120v Motor / Slide Assembly 05965 120v Motor / Slide Assembly for Swivel			
Item	Part #	Description	Qty
1	05479	Motor Assembly	1
a	19021	Motor Label	1
b	04528	Motor Specs Label	1
c	19033	Motor Cord	1
d	11053	Screw BHC #8-32 X 3/16	1
e	10538	#8 Washer	1
f	04502	Inspection Cover	1
g	75289	Screw M5 X 8mm	2
2	04500	Dove Tail Slide (05485 Assy.)	1
	05824	Dove Tail Slide (05965 Assy.)	1
3	02428	Rack Gear (05485 Assy.)	1
	05825	Rack Gear (05965 Assy.)	1
4	02422	Motor Cord Bracket	1
5	41044	Screw BHC #10-32 X 3/8	2
6	75156	Screw SHC M6 X 1 X 15mm	4
7	40038	Screw SHC #10-32 X 5/8	1
8	90077	Screw BHC #10-32 X 1/2	1
9	10560	#10 Lock Washer	2
10	90028	1/4 Lock Washer	4
11	05057	Bottle Bracket	1
12	05988	Screw FHC #10-32 X 1/2	2
13	05185	1/4 X 3/8 lg.	1




07182 230v Motor / Slide Assembly			
07183 230v Motor / Slide Assembly for Swivel			
Item	Part #	Description	Qty
1	07184	Motor Assembly 230v	1
a	19021	Motor Label	1
b	04042	Motor Specs Label	1
c	19033	Motor Cord	1
d	11053	Screw BHC #8-32 X 3/16	1
e	10538	#8 Washer	1
f	04502	Inspection Cover	1
g	75289	Screw M5 X 8mm	2
2	04500	Dove Tail Slide (07182 Assy.)	1
	05824	Dove Tail Slide (07183 Assy.)	1
3	02428	Rack Gear (07182 Assy.)	1
	05825	Rack Gear (07183 Assy.)	1
4	02422	Motor Cord Bracket	1
5	41044	Screw BHC #10-32 X 3/8	2
6	75156	Screw SHC M6 X 1 X 15mm	4
7	40038	Screw SHC #10-32 X 5/8	1
8	90077	Screw BHC #10-32 X 1/2	1
9	10560	#10 Lock Washer	2
10	90028	1/4 Lock Washer	4
11	05057	Bottle Bracket	1
12	05988	Screw FHC #10-32 X 1/2	2
13	05185	1/4 X 3/8 lg.	1

120V MOTOR PARTS DIAGRAM




05479 120v MOTOR ASSEMBLY




MOTOR PARTS LIST

Part #	Description	Qty	Part #	Description	Qty
04502	Brush Cover	1	17613	Flat Washer	1
04528	Label, Motor Safety	1	17614	Gear Housing	1
05462	Spindle	1	17617	Fan Guide	1
05474	Motor 120v	1	17618	Gasket	1
10538	Washer #8	1	17630	Armature	1
11053	Scew BHS #8-32	1	17628	Field	1
17600	Field Case	1	17621	Carbon Brush (Pack of 2)	1
17601	Gear Housing	1	17622	Brush Cap	2
17602	Ball Bearing	2	17623	Pan Head Screw	2
17603	Ball Bearing	1	17624	Pan Head Screw Short	2
17604	Ball Bearing	1	17625	Pan Head Screw Long	2
17605	Ball Bearing	1	17626	Retaining Ring	1
17606	Dust Seal	1	17627	Retaining Ring	1
17607	1st Inter. Gear Assy	1	17632	Paper Washer	2
17608	2nd Inter. Gear Assy	1	17679	Brush Holder	2
17609	Spur Gear	1	19021	Label, Motor	1
17610	Flat Washer	1	19033	Motor Cord	1
17611	Key	1	75289	Pan Head Screw	2
17612	Dowel Pin	1			

230V MOTOR PARTS DIAGRAM



07184 230v MOTOR ASSEMBLY



MOTOR PARTS LIST

Part #	Description	Qty	Part #	Description	Qty
04042	Label, Motor Safety	1	17612	Dowel Pin	1
04502	Brush Cover	1	17613	Flat Washer	1
05462	Hex Spindle	1	17614	Gear Housing	1
05475	230v Motor	1	17616	Spindle	1
05519	Carbon Brush 230v	2	17617	Fan Guide	1
10538	Washer #8	1	17618	Gasket	1
11053	Screw BHS #8-32	1	17622	Brush Cap	2
17600	Field Case	1	17623	Pan Head Screw	2
17601	Gear Housing	1	17624	Pan Head Screw Short	2
17602	Ball Bearing	2	17625	Pan Head Screw Long	2
17603	Ball Bearing	1	17626	Retaining Ring	1
17604	Ball Bearing	1	17627	Retaining Ring	1
17605	Ball Bearing	1	17629	Field	1
17606	Dust Seal	1	17631	Armature	1
17607	1st Inter. Gear Assy	1	17632	Paper Washer	2
17608	2nd Inter. Gear Assy	1	17679	Brush Holder	2
17609	Spur Gear	1	19033	Motor Cord	1
17610	Flat Washer	1	19048	Label, Motor	1
17611	Key	1	75289	Pan Head Screw	2

MAINTENANCE

In order to minimize wear on moving parts and to insure smoother operation and longer life for your magnetic drill, the following maintenance should be done periodically, based on use.

1. Regularly tighten all fasteners and replace all worn parts.
2. Check motor brushes and replace if worn. (Break in period - 30 minutes at no load speed)
3. Check power cord and cord from panel to motor and, if cracked or frayed, return to an authorized repair center for replacement.
4. Apply grease to the slide dovetails, brass gibs, and the feed gear rack. For best results use Shell Cyprina-RA or equivalent.
5. Remove arbor and pack the bearing in the front support bracket with grease. Use Shell Cyprina-RA or equivalent.

REMEDIES FOR HOLEMaking PROBLEMS

- 1. Trouble: Magnetic base won't hold effectively to work.**
 - a. Cause: Chips or dirt under magnet.
Remedy: Clear area of chips and dirt.
 - b. Cause: Irregular surface on bottom of magnet or on workpiece.
Remedy: Lightly surface grind the bottom of the magnet flat and/or file imperfections flat on the work surface as needed.
 - c. Cause: Dull cutter.
Remedy: Use a sharp cutter. A dull cutter will cause lift of magnet.
 - 2. Trouble: Cutter tends to move across surface of work.**
 - a. Cause: Magnetic base not holding effectively.
Remedy: See causes and remedies under No. 1 above.
 - b. Cause: Too much feed pressure at start of cut.
Remedy: Light pressure until a groove is cut. The groove then serves as a stabilizer.
 - c. Cause: Worn pilot.
Remedy: Replace pilot.
 - d. Cause: Misaligned or loose arbor set screws.
Remedy: Tighten set screws.
 - 3. Trouble: Out of round holes.**
 - a. Cause: Worn arbor support bracket bearing and or collar.
Remedy: Replace: (only a few thousandths wear permissible.)
 - b. Cause: Misaligned support bracket.
Remedy: Realign support bracket.
 - c. Cause: Misaligned or loose arbor set screws.
Remedy: Tighten set screws.
 - 4. Trouble: Motor and slide won't stay in set position**
 - a. Cause: Gibs too loose
Remedy: Adjust gibs
 - 5. Trouble: Erratic or intermittent feed.**
 - a. Cause: Worn pinion and/or rack.
Remedy: Replace worn parts.
 - 6. Trouble: Motor doesn't run when motor START switch is pushed.**
 - a. Cause: Magnet is not turned on
Remedy: Push magnet ON button.
 - b. Cause: Magnet on rough or dirty work surface and safety switch not fully depressed.
Remedy: File work surface flat and clean all chips and oil from under magnet.
 - c. Cause: Safety switch broken.
Remedy: Replace safety switch.
 - d. Cause: No power.
Remedy: Check power source and extension cords.
 - e. Cause: Worn motor brushes
Remedy: Replace brushes
 - f. Cause: Faulty motor START switch
Remedy: Return unit to an authorized repair center to have switch replaced.
 - 7. Trouble: Feed Motor doesn't feed Arbor.**
 - a. Cause: Feed engagement not turn on
Remedy: Pull Feed Engagement ON.
 - b. Cause: Power/Manual Feed not flipped to Power Feed.
Remedy: Flip switch to Power Feed.
- NOTE: If you are unable to correct any malfunction after trying the above, do not attempt to operate the drill. Return the unit to the factory or authorized repair center for service.**

HINTS FOR SMOOTHER OPERATION

1. Keep inside of Hougen Cutter clear of chips. Chips will interfere with cutting to maximum depth and may impede the free oil flow and can cause cutter breakage.
2. Keep work, machine, arbor and Hougen Cutter free of chips and dirt.
3. Tighten all bolts and fasteners regularly.
4. We highly recommend using a light viscosity cutting fluid (preferably Hougen Cutting Fluid - Part No. 11742-4)
5. Occasionally check metering of cutting fluid flow. Lack of cutting fluid may cause Hougen Cutter to freeze in cut, slug to stick and may result in poor cutter life.
6. Always start cut with light feed pressure and then increase sufficiently to achieve maximum cutting rate.
7. Ease off on pressure as cutter begins to break through at the end of the cut.
8. Keep slide dovetails, brass gibs and feed rack lubricated and free of chips and dirt.
9. When slug hangs up in cutter, turn off motor and bring cutter down on a flat surface. This will normally straighten a cocked slug, allowing it to be ejected.
10. When cutting large diameter or deep holes it may be necessary to stop in the middle of the cut to add cutting fluid and remove the chips from around the arbor. (When doing this DO NOT raise the cutter out of the hole. Doing so can allow chips to get under the teeth of the cutter and make it difficult to restart the cut.)
11. **In power feed mode. A dull cutter will cause lift of the magnet be sure to always use a sharp cutter.**

#1 cause of cutter breakage and prematurely dull teeth is too little feed pressure*

*** "Babying" the cutter through the cut will only decrease tool life.**